




Position	Spare parts	Part number
1	Inverter board	033091300000
2	PC board (Heat&Cool)	033090310500A28
3	Touch controller with built-in wifi	034092180001
4	Power filter plate	033092330000
5	Reactor(big)	041301080000
6	Electronic expansion valve	006121000001
7	4-way valve	006110080001
8	Water flow switch	040060620000
9	Fan motor	032051700000
10	Full set of sensors	Z35043000400
11	Compressor	031064020000
12	Titanium heat exchanger(Heat&Cool)	001031200003
13	Evaporator	Z01011480000
14	High pressure protection switch	040050630000
15	Low pressure protection switch	040050130000
16	Low Pressure valve	006080500000
17	Liquid reservoir	/
18	Water union (Black, 50mm)	003990020000
19	Water union gasket	004980050002
20	Fan	007010030000
21	Drainage kit	Z03991700000
22	Compressor insulation cap	004041710000
23	Top cover	Z02020621515
24	Front Panel	Z020206202P1
25	Right Up Panel	Z02020623015
26	Right Down Panel	Z020206218P1
27	Back Panel	0020206253P1
28	Bottom board	002020625000
29	Pole	0020206306P1
30	Left mesh board	Z020206222P1