






Position	Spare parts	Part number
1	Inverter board	033091410400
2	PC board (Heat&Cool)	033090310400A51
3	Touch controller with built-in wifi	034092180001
4	Power filter plate	033092340000
5	Reactor (big)	041301100000
6	Electronic expansion valve	006121010001
7	4-way valve	006110210001
8	Water flow switch	040060620000
9	Fan motor	032051700000
10	Full set of sensors	Z35043000400
11	Compressor	031064060000
12	Titanium heat exchanger (Heat&Cool)	001031220003
13	Evaporator	Z01010650000
14	High pressure protection switch	040050630000
15	Low pressure protection switch	040050130000
16	Low Pressure valve	006080500000
17	Liquid reservoir	/
18	Water union (Black, 50mm)	003990020000
19	Water union gasket	004980050002
20	Fan	007010170000
21	Drainage kit	Z03991700000
22	Compressor insulation cap	004041730000
23	Top cover	002020591115
24	Front Panel	0020205905P1
25	Right Up Panel	002020592515
26	Right Down Panel	0020205913P1
27	Back Panel	0020205935P1
28	Bottom board	002020595000
29	Pole	0020205906P1
30	Left mesh board	0020205918P1