



Position	Spare parts	Part number
1	Integrated board (Heat&Cool)	033093541500A33
2	Oval touch controller	034093010301
3	Power filter plate	033092330000
4	Reactor(big)	041301100000
5	Electronic expansion valve	006121000001
6	4-way valve	006110080001
7	Water flow switch	040060620000
8	Fan motor	032051700000
9	Full set of sensors	Z35043000400
10	Compressor	031064020000
11	Titanium heat exchanger (Heat&Cool)	001031110003
12	Evaporator	Z01011700000
13	High pressure protection switch	040050630000
14	Low pressure protection switch	040050130000
15	Low Pressure valve	006080500000
16	Liquid reservoir	/
17	Water union (Black, 50mm)	003990020000
18	Water union gasket	004980050003
19	Fan	007010030000
20	Drainage kit	Z03991700000
21	Top cover	002021711500
22	Front Panel	0020217104Z1
23	Right Up Panel	0020217105Z1
24	Back Panel	0020217106Z1
25	Bottom board	002021710100
26	Back mesh board	0020217102Z1
27	Left mesh board	0020217103Z1