



Position	Spare parts	Part number
1	Integrated board (Heat&Cool)	033093562200A56
2	Oval touch controller	034093010301
3	Power filter plate	033092370000
4	Reactor(big)	041301110000
5	Electronic expansion valve	006121110001
6	4-way valve	006110160001
7	Water flow switch	040060620000
8	Fan motor	032051720000
9	Full set of sensors	Z35043000400
10	Compressor	031076000000
11	Titanium heat exchanger (Heat&Cool)	001031400003
12	Evaporator	Z01011710000
13	High pressure protection switch	040050630000
14	Low pressure protection switch	040050130000
15	Low Pressure valve	006080500000
16	Liquid reservoir	006090040000
17	Water union (Black, 50mm)	003990020000
18	Water union gasket	004980050003
19	Fan	007010080000
20	Drainage kit	Z03991700000
21	Top cover	002021731600
22	Front Panel	0020217304Z1
23	Right Up Panel	0020217305Z1
24	Back Panel	0020217306Z1
25	Bottom board	002021735100
26	Back mesh board	0020217302Z1
27	Left mesh board	0020217303Z1