



Position	Spare parts	Code
1	Integrated board(Heat & Cool)	033093522000A23.1
2	Oval touch controller	2005020900012
3	Power filter plate	033092360000
4	Reactor (big)	041301090000
5	Electronic expansion valve	2002010200022
6	4-way valve	006110080001
7	Water flow switch	040060620000
8	Fan motor	032051680000
9	Full set of sensors	Z35043000400
10	Compressor	031064010000
11	Titanium heat exchanger (Heat & Cool)	001031440003
12	Evaporator	001011760000
13	High pressure protection switch	040050630000
14	Low pressure protection switch	040050130000
15	Low Pressure valve	006080500000
16	Liquid reservoir	/
17	Water union (Black, 50mm)	003990020000
18	Water union gasket	004980050003
19	Fan	007010140000
20	Drainage kit	Z03991700000
21	Top cover	002021751700
22	Front Panel	1220020300698
23	Right Up Panel	0020217504Z1
24	Back Panel	0020217505Z1
25	Bottom board	'002021750100
26	Back mesh board	0020217502Z1
27	Left mesh board	1220020300671