



Position	Spare parts	Part number
1	Integrated board (Heat&Cool)	2005030200055A23
2	Oval touch controller	2005020900011
3	Power filter plate	033092360000
4	Reactor (big)	041301090000
5	Electronic expansion valve	2002010200022
6	4-way valve	006110080001
7	Water flow switch	040060620000
8	Fan motor	1201020100013
9	Full set of sensors	Z35043000400
10	Compressor	031064000000
11	Titanium heat exchanger (Heat&Cool)	2001020100151
12	Evaporator	1202010200136
13	High pressure protection switch	040050630000
14	Low pressure protection switch	040050130000
15	Low Pressure valve	006080500000
16	Liquid reservoir	1203020300012
17	Water union (Black, 50mm)	003990020000
18	Water union gasket	004980050003
19	Fan	007010140000
20	Drainage kit	Z03991700000
21	Top cover	1220020103716
22	Front Panel	1220020302239
23	Right Up Panel	1220020302072
24	Back Panel	1220020302241
25	Bottom board	1220020103717
26	Back mesh board	1220020302240
27	Left mesh board	1220020302069